

## Materials

- [1 Yard Fabric](#)
- [1 Yard Fusible Interfacing](#)
- [Thread](#)

## Tools

- [Iron or heat press](#)
- [Thread Clippers](#)
- [Sewing Clips](#)
- [Scissors](#)
- [Pencil](#)
- [Rotary Cutter, Cutting Mat, & Ruler](#)

## Instructions

1. Cut two pieces of 20-inch fabric and however wide you'd like the organizer to be. I did 15 inches across. Cut two pieces of 9-inch by 15-inch. Cut one 20-inch by 15-inch of the interfacing.
2. Take the two pieces of 8-inch and place right sides facing and stitch all around leaving a small 2-inch hole at the bottom for flipping.
3. Flip right side in.
4. Fold in the hole and press.
5. Place one piece of the 20 by 15 face side up.
6. Place the 9-inch piece on top near the bottom with the hole to the bottom.
7. Press interfacing to the wrong side of the other 20 by 15 piece.
8. Place this piece right side down on top of the other two pieces above. Clip and stitch all the way around leaving a 2 inch opening at the bottom.
9. Flip right side in.
10. Press hole and entire organizer flat. Topstitch around the entire outside.
11. Once top stitched you can now topstitch across the pocket.
12. Just measure where you would like the pockets. Mark them then sew from top to bottom on the pocket.
13. Enjoy your bedside organizer.



